

SPC-E120.100
Acre SPCE120.100 – Indication And Control Expander

Description

The Acre SPCE120.100 expander is a valuable addition to any Acre intrusion security system. This versatile device provides a user-friendly interface, customizable control options, and enhanced system visibility, making it ideal for improving overall security management and user experience.

Key Features:

- **16 Tri-Colour LED Indicators:** Provide a clear visual representation of system status, including zone activity, area settings, and alerts.
- **4 Programmable Function Keys:** Set button functions to suit your needs, such as setting/un-setting areas, triggering actions, or controlling external devices.
- **Integrated Card Reader:** Enhance security and convenience by allowing users to control the system with a valid proximity card.
- **Linked Mode:** When paired with a keypad, the LEDs display the status of 4 specific areas, and the function keys can be assigned to directly set or unset those areas.
- **Flexible Mode:** Create a custom user interface by programming the LEDs to display any configured status information (e.g., open zones, area setting states). The function keys can also be programmed to trigger specific actions based on user input.
- **Freely Programmable Zone:** The expander includes one configurable zone that can be used for various monitoring applications, adding an extra layer of security to your system.
- **Tamper Protection:** Front and back tamper contacts ensure the integrity of the expander and system reliability.



Product Specifications

| | |
|--------------------|----------------------------|
| Weight | kg |
| Brand | ACRE |
| Series | <i>Acre Intrusion, SPC</i> |
| Device-type | <i>Expander</i> |
| Grading-compliance | <i>Grade 3</i> |

